

## Stick-screwdriver for the Alu-holder-montage

## RU-CS-ST-M

For the assembly of squared clip and pivot aluminium holders.

**RU-CS-ST-M, stick-screwdriver** with auto. screw-feeding and alu-holder box for pivot - or clip holders. The feeding-duct will be adjusted to the alu-holder. The screwdriver will be guided manually and decreed over a turning-moment cut-off. The rotary- or clip holder will be stored in a box and feed manually in correct position. Over compressed air the holder will be agreed in the right screw-position. Optional it is possible to screw rotary- and clip holders in the same geometric design. The box also be used as arrester-disc from above over two position-surfaces over raster-bolt the intervals in the depth can be adjusted. If you have more than 3 screw-positions in the depth it is advisable to use a position-arrester-kit each for the sash and for the frame. The distance-measure in the depth must be declares when you order.



### Technical Data :

Type	Description	Order-Nr.
RU-CS-ST-M	Stick-screwdriver	10555000
RU-WAL-C	Trolley	10267000
	Position beds stop	6903
	Balancer 2 - 3 kg	6308-1
	Fixture for screw-feeding-unit	6307